

Desktop air purifier

AP070A

The product is subject to the actual product in the package
This manual contains a warranty card, please keep it properly

Dear users, thank you for using our products. In order to facilitate your correct operation of this product, please read this manual carefully before using and store it in a fixed place so that you can refer to it when you need it.

/ Precautions /



Warning: Please follow the instructions below to avoid any physical injury!

Note: If you do not follow the instructions below, it may cause physical injury or damage the product

warning

- Do not spray any paint, insecticide, alcohol or chemicals on the surface of the machine. Otherwise, it may cause surface cracking, electric shock, or fire.
- If there are pharmaceutical ingredients accumulated in the machine, it will be released from the air outlet as the machine is turned on, which is not good for health. Therefore, after using pesticides, please fully ventilate the room.
- Air purifier products should not be used in flammable, explosive and corrosive gas environments.
- When the machine is running, do not touch the air inlet and outlet. Do not insert your hands or any objects into the air inlet and outlet to avoid injury or damage to the air purifier product.
- Do not place objects on the machine, otherwise it is easy to cause accidental loss or injury.
- Please do not use it in the bathroom or other places with water. Otherwise, it may cause fire, electric shock, malfunction, etc.
- Do not modify, disassemble or repair the machine without authorization, otherwise it may cause fire, electric shock, malfunction, etc.

Note

- If the power cord or plug is damaged, it may cause electric shock or fire, so please do not use it. Do not touch the power cord with wet hands.
- When moving the machine or performing maintenance on the machine, be sure to turn off the machine and unplug the power cord.
- When not in use for a long time, please unplug the power cord from the socket.
- When the machine has a peculiar smell, stop using it and cut off the power, and contact the after-sales personnel for inspection to avoid malfunction or fire.
- The air outlet is easy to fall into the sundries, please check before use to prevent young children from putting sundries in.
- The air purifier should be placed at least 50cm away from walls or other obstacles.
- If the power supply is damaged, in order to avoid danger, it must be replaced by the manufacturer or other maintenance department or similar full-time personnel.
- Children and people with disabilities must be under the supervision of a guardian to use the machine.
- Supervised children are not allowed to use the product as a toy, and it is strictly forbidden to play or step on the product.


/ Product specification/

Product name: Multifunctional air purifier
Product Size: $\varnothing 162.5 \times 242.7 \text{mm}$
Rated voltage: DC 12V
Humidity environment: 10%~95%
Executive standard: CADR:53CFM


Model: AP070A
Net weight: 1.1kg
Power: 6W
Working temperature: $-4^{\circ}\text{C} \sim +50^{\circ}\text{C}$

/ product structure /


·Front view




·Rear view



·Bottom view



/ Button name and function description /




• Power-on

- ① Plug in the power adapter, within 1 second of turning on the power, the buzzer will sound for 0.5 seconds. After all the indicators are flashing for 0.5s, the backlight of the power button is half bright and white, and all other indicators are off, and the machine is in standby.
- ② In the power-on state, press any function key to wake up the screen.

• ON/OFF Button

- ① Press the power button in standby mode, the backlight of the power button is fully on, the buzzer beeps for 0.1 seconds, the machine enters the "1" gear work; the "1" gear LED indicator is on, the LED brightness is 100%; the backlight of the gear button is 100% bright, the timer is 100% bright, the light button is 100% bright, the decorative light is 100% bright, the night light replacement filter indicator is not on. 100% brightness of gear button backlight and timing backlight, 100% brightness of light button backlight, 100% brightness of decorative light, night light to replace the filter indicator is not on.
- ② Press the power button in any working state, the buzzer beeps for 0.1 seconds, the power indicator light is half on, and all other LED lights are off, the machine stops working and returns to the standby state.
- ③ When the machine is turned on in standby mode, the machine will not memorize the last setting of timer and night mode, but it will memorize the working gear before the last shutdown.

• Fan Speed Button

- ① Press this button in the power-on state , the buzzer will beep for 0.1 seconds, and the machine will jump into gear 2. The "2" gear indicator lights up, the LED brightness is 100%, and the motor starts to work in gear 2;
- ② In the "2" mode, press the gear button once, the buzzer will beep for 0.1 seconds, and the machine will work in gear 3. The "3" gear indicator lights up, the LED brightness is 100%, and the motor starts to work in gear 3;
- ③ In the "3" mode, press the gear button once, the buzzer will beep for 0.1 seconds, the machine will work in the gear 1, and the working mode of the machine will cycle as described above;


• Timer Button

- ① Press this button in the power-on state, the timing 2H backlight LED will light up; press the timing button again, the timing 4H backlight LED light will turn on; press the timing button again, the timing 8H backlight LED light will turn on; press the timing button again, all the timing LED lights are off (Timer is off), press the timing button again, the backlight LED for 2 hours will light up, and cycle according to this, the timing does not accumulate.
- ② After setting the time, the machine will work in the current working state. After the set time is reached, the machine will automatically shut down and return to the standby state.

• Night light

- ① Under Power on state, press the night button to enter night mode, buzzer beeps for 0.1 second, decorative lights go out, the button of the current operating function gear indicates 50% brightness. Then press the night button to turn off the night mode, buzzer beeps for 0.1 second, button lights indicate 100% brightness, decorative lights indicate 100% brightness. Repeat the above procedures to cycle.
- ② The timer and wind speed gear can be operated in the night mode, the indicator light will stay 50% brightness.

• Check Filter Indicator

- ① The machine is equipped with a high-efficiency filter, under normal power on state, the filter replacement indicator will not light up when the filter life > 10%. The filter replacement indicator will light up to 100% brightness when the filter life remains ≤ 10%, to remind the user to replace the filter.
 - ② After the high-efficiency filter is replaced, press the filter replacement icon  for 3 seconds, the buzzer will beep for 0.1 second, the filter life indicator will stop flashing, the filter LED will go out, and the machine will return to normal working status;
- Recommended filter replacement 3–6 months

/ common problem /

Failure phenomenon	Check items	elimination method
The air purifier does not turn on	Whether the power socket has electricity	Power on
	Whether the power socket is loose	Connect the power
	Check whether the filter plastic bag has been removed	Open the filter compartment door and check if the filter plastic bag is removed
When the purification function is turned on, the sound is dull and the wind is small	Whether the air outlet is covered	Turn off the purifier and remove the covering
The air outlet has a peculiar smell	Whether there is a large amount of peculiar smell near the air inlet that continues to release	After removing the peculiar smell and letting the purifier run for a period of time, the peculiar smell will gradually disappear
	The filter needs to be replaced	Check the dirtiness of the filter, consider replacing the filter

* The product may be accompanied by a slight peculiar smell in the early stage of use, which is a normal phenomenon; the life of the filter may be different due to the different use environment of the consumer's air purifier

/ Cleaning and maintenance/

In order to improve the service life of the air purifier, please maintain the air purifier regularly. Before and during maintenance, please turn off the purifier and unplug the purifier from the power supply.

After the air purifier is used, if the filter needs to be replaced, the red breathing light of the filter replacement indicator on the control panel flashes to remind the user the old filter needs to be replaced .

• Clean appearance

When cleaning the appearance of the air purifier, please turn off the power first and clean it with a soft clean dry cloth. Do not use chemical solvents such as alcohol or gasoline for cleaning.

• Remove the PE bag


Before using the air purifier for the first time, please open the air purifier filter compartment door to take out the filter, and be sure to take out the adapter and filter packing bag, otherwise the product cannot purify the air normally.

(* Please keep plastic bags away from infants and young children to avoid accidents when infants and young children come into contact with plastic bags.)




• Clean or replace the filter

Replace the filter: Lay the air purifier flat, hold the handle of the filter compartment door and rotate it to the right, and remove the filter compartment door.



Take out the old filter, place the new filter, aim the filter compartment door at the bottom, and turn it to the left to tighten it.

(*Special reminder: The filter cannot be washed)



/ Product name and content table of hazardous substances /

Part Name	Pb	Hg	Cd	CrVI	PBB	PBDE
Fasteners such as screws	○	○	○	○	○	○
Controllers and electrical devices	○	○	○	○	○	○
Motor	○	○	○	○	○	○
Other plastic parts	○	○	○	○	○	○
Power cord assembly	○	○	○	○	○	○
Packaging and printing components	○	○	○	○	○	○

This form is compiled in accordance with the provisions of SJ/T 11364.

- : It means that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirement specified in GB/T26572.
- X : It means that the content of the substance in at least a certain homogeneous material of the part exceeds the limit requirement of GB/T26572.

/ Pay attention to environmental protection/



Pay attention to environmental protection!

Please abide by local regulations: put waste electrical products and equipment in a suitable waste recycling station.